



3R Odor-Con/Purogene Sales ♦ 1980 Palomino Trl ♦ McPherson, KS ♦ 67460
620-241-1304 ♦ 800-773-7116
www.3rodorcon.com sales@3rodorcon.com

3R ODOR-CON

WHAT IS IT?

3R ODOR-CON contains 2% ClO₂ (Chlorine Dioxide) in a stabilized form. Being stabilized, it takes something to activate it. All odors are acidic which activates **3R ODOR-CON** and causes it to release ClO₂. The ClO₂ breaks down and destroys the odor molecules. The odor is gone. Only enough ClO₂ is released to control the amount of odor generated, the rest lays and waits until it's needed. **3R ODOR-CON** is environmentally safe. It causes **no** damage to septic systems or sewage treatment plants.

It helps break down all waste and paper, (you do not have to use special paper, any paper that fragments in water will do), cleans the tanks, cleans the valves, has no odor or perfume smell. It destroys odors by oxidation. There will be very little odor when you dump.

HOW TO HAVE CLEAN ODOR FREE HOLDING TANKS

1. Dump the tanks, if they haven't already been dumped. Black tank first, Gray second, gray water will flush the black water from the hose.
2. Use 1 ounce (2 tablespoons) of **3R ODOR-CON** per 60-gallon black and gray water tanks. Add the **3R ODOR-CON** to 1 to 1 1/2 gallons of water and pour into the black tank through the commode. Repeat this for the Gray water tank dividing it between the kitchen sink, bathroom sink, and shower.
3. Start using your utilities as you normally would. If this is the first time using **3R ODOR-CON**, if possible, allow the tanks to get full before dumping. This allows **3R ODOR-CON** to come in contact with all the interior surfaces of the tanks.
4. Odors cling to and are on the interior surfaces of the tanks, even at the top. From time to time allow the tanks to get full or top them off with water before dumping. This allows the **3R ODOR-CON** to reach the odors and leave a coating on the tank surfaces to attack the odors coming off new effluent.
5. **DO NOT RINSE AFTER YOU DUMP.** **3R ODOR-CON** leaves a coating that continues to work removing the scum line and any newly generated odor in the black water tank.
6. Vehicles which are being placed in storage, or a holding position pending further use, should be treated the same way as for active use. Also, check the traps in commode, bathroom sink, shower, and kitchen sink to be sure they have water in them. After long periods of sitting, they can dry out.
7. If you must dump before the tanks are full, and cannot top them off, add five (5) gallons of water and the appropriate amount of **3R ODOR-CON** to the tanks. Drive to your next location. If the trip is over 50 miles, the tanks should have acquired a sufficient coating to control the odor.
8. To keep the Gate Valve clean and remove urine odors from porous plastic commodes, pour 1/2 gallon of the **3R ODOR-CON**/water mix from step 2 into the commode after the last use of the day and allow it to sit there until the next use.

3R ODOR-CON SHOULD BE STORED IN A COOL, DARK PLACE